


Schaltplatte kpl. Nr. 7392-092
PRINTED BOARD N. 7392-092

Anschlußschaltbild Nr. 53-6229-1101 Blatt 1
ADDITIONAL CIRCUIT DIAGRAM N. 53-6229-1101
SHEET 1
Gültig ab Gerät Nr. 1201
FOR SETS FROM SERIAL N. 1201
Änderungen vorbehalten!
ALTERATIONS RESERVED!



PRINTED IN GERMANY

R: 227	231	228	239	213	243	211
R: 230	214	229	232	238	212	
C:	201	205		212	211	

47/B21																			
46	210	219	234	209	205	208	217	207											
73	220	228	240	204	206	201	218	233	216	232	230								
3	221	222	208	234	203	207	206												
										263/B30	262/B31								
												203	227	215					

Elektrolyt
ELECTROLYTIC

250V- Keramik
CERAMIC

Wobbelsender WS4
(53-6229-1101)
Blatt 2

